

212CC Go kart

Assembly Instructions



Model:FR200GK / GK014

PLEASE NOTE THAT THIS IS NOT THE OWNER'S MANUAL BUT THE ASSEMBLY INSTRUCTIONS ONLY.

BEFORE OPERATING THIS GO-KART, MAKE SURE THE OPERATOR AND PASSENGER HAVE READ AND UNDER STAND THE OWNER'S MANUAL, WARNING LABELS AND ARE FAMILIAR WITH ALL GO-KART CONTROLS.

REMOVAL FROM CRATE

1. Remove the metal crate from the Go-Kart.
2. Locate and get out Owner's/Operator's manual, set up instructions and all documentation.

Note: Read Owner's / Operator's manual thoroughly before starting Go-Kart for the first time.

3. Locate and remove all parts and hardware from crate and set aside.

Note: Some hardware may already be mounted on the Go-Kart. This will have to be removed and then re-attached during assembly.

Wheel Parts



Front Tires



Rear Tires



Rear Rack



Steering Wheel



Brush Guard Parts



Main Brush Guard




Brush Guard Side Support




Brush Guard Cross Braces



Seat



Safety Belt



Rear Protective Net

REAR WHEEL ASSEMBLY

Hardware:

- M20 Spring lock washer 2ea. (1)
- M20 Locking nuts 2ea. (2)
- M20 Large washer 2ea. (3)



1. Lift the Kart with a jack.

Note: Make sure tire tread faces forward and Air valve stem is on the outside of the tire when installing.




↑ Make sure the trend faces forward



2. Install rear tire assembly in the following order:


- 1. Wheel
- 2. M20 Large washer (3)
- 3. M20 Spring lock washer (1)
- 4. M20 Locking nuts (2)



FRONT WHEEL ASSEMBLY

Hardware:

- M14 Spring lock washer 2ea. (1)
- M14 Flange nuts 2ea. (2)



1. Lift the Kart with a jack.

Note: Make sure tire tread faces forward and Air valve stem is on the outside of the tire when installing.




↑ Make sure the trend faces forward



2. Install rear tire assembly in the following order:

- 1. Wheel
- 2. M14 Spring lock washer (1)
- 3. M14 Flange nuts (2)



STEERING WHEEL INSTALLATION

Hardware:

M8X35 Bolts 1ea.(1)

M8 Cap Nuts 1ea.(2)


1



2



1. Attach steering wheel with Steering column using M8 bolt (1) and M8 nut (2).



SEAT INSTALLATION



Hardware:

M8 Flange Nuts 4 ea. (1)

1



1. To install the seat, attach the bolt, located on the bottom of the seat, to the bracket on the Go Kart before tighten the M8 nuts(1).



SAFETY BELT INSTALLATION

Hardware:

M10×1.25 Flange nuts 6ea.(1)

M10×25×1.25 Bolts 6ea.(2)

M10 Washer 6ea.(3)

1




2




3



1. Install the self belt on the frame with M10×25×1.25 Bolts(2), M10 washer(3) and M10×1.25 Flange nuts(1).




Place bottom portion of the belt through the seat.



BRUSH GUARD INSTALLATION

Hardware:

M8 X 45 bolts	4 ea. (1)
M8 X 40 bolts	6 ea. (2)
M8 Cap Nuts	6 ea. (3)
M8 Large washer	10 ea. (4)
M8 Concave Washers A	4 ea. (5)
M8 Concave Washers B	10 ea. (6)



1. Attach Main Brush Guard with M8x35 bolts(2) and M8 nuts (3).


Note: Do not tighten bolts at this time, keep bolts loose until the brush guard is completely assembled.



M8x40 bolts and M8 cap nuts


2. Attach center and side supports with M8 Concave Washers A&B (5)&(6), M8 Large washers(4) and M8x45 Bolts(1).

Tighten all bolts on rack and Brush Guard assembly.



REAR SAFETY NET

1. Attach safety net on brushguard.



REAR RACK INSTALLATION



Hardware:

M8x16 bolts 4 ea.(1)

M8 nuts 4 ea. (2)



Assemble the rear rack to the roll mounting point with Flange bolt M8x16(1) and nut M8(2).



PRE-RIDE INSPECTION

Inspecting and checking the condition of the Go Kart before each ride is important. Following the pre-ride check list will help insure the you do not have mechanical problems which could result in injury or becoming stranded. Make sure the Go Kart is in good operating condition before each ride.

WARNING

Failing to inspect and maintain your Go Kart could be hazardous.

Not following the pre-ride inspection procedures could result in loosing control of the Go Kart resulting in an accident or damage to the Go Kart

Always perform a Pre-ride inspection before each ride.

WARNING

Performing maintenance and checks while the engine is running could be hazardous.

You could be severely injured by moving parts or hot surfaces.

Never perform maintenance or check procedures while the engine is running with the exception of checking the ignition switch or throttle.

WHAT TO CHECK	CHECK FOR
Steering	• Smoothness • No restriction of movement
Brakes	• Correct fluid level • Inspect hoses for leaks • Inspect brake pads for wear.
Tires	• Proper tire pressure • Proper tread depth • Rubber has no cracks
Fuel Tank	• Enough fuel for the ride • Fuel cap secure • Hoses have no signs of cracks or leaks
Throttle Pedal	• Pedal snaps back to idle when released • Operates freely
Engine Ignition switch	• Switch shuts off engine when activated.
Engine Oil	• Correct oil level
Torque Converter Guard	• No damage • Securely attached
Drive Chain	• Proper tension • Lubricated • No excessive wear or damage
General Condition	• All nuts and bolts tight • No rattles from engine or frame while running

⚠ WARNING

Never Attempt to start this Go-Kart without reading and understanding the Owner's/Operator's manual. The Owner's/Operator's manual provides information on safety, parts, functions, pre-ride inspection, starting and maintenance.