



USER'S MANUAL

Golf Caddy

TERRA MANUAL



SUMMARY

1	General Cautions	4
2	Packing list	5
2.1	Terra manual BASE VERSION	Errore. Il segnalibro non è definito.
2.2	Terra manual FULL VERSION	5
3	Main parts	6
3.1	Description of main part	6
4	Assembly instruction	7
4.1	Braking system	9
4.2	Accessories	9
5	Maintenance	10
5.1	Troubleshooting guide	10
6	Technical data	11
7	Customer service - technical assistance	12



I General Cautions



FIRST USE

- Read the user manual carefully before using the caddy.

DANGER!!



- Only use the caddy in a private area, closed to traffic.
- Do not allow the use of the caddy by children under 12 years of age.
- Do not use the caddy for anything other than its intended purpose (transport of a bag for clubs).
- Do not use the caddy to transport people, animals or things.
- Do not exceed the maximum capacity of the caddy (85 lbs).



2 Packing list

2.1 Terra manual FULL VERSION

1 Frame with front wheel	1 Rudder frame and controls
1 Axis frame	1 Tool kit
2 Rear wheels	1 Rain cover
1 Score card holder	1 GPS/phone holder
1 Cup holder	1 Umbrella holder
1 Multi support	1 Carry on trolley bag



3 Main parts



3.1 Description of main part

Ref.	Description	Ref.	Description
1	Rudder frame	5	Brake lever
2	Rudder adjustment knob	9	Front frame
3	Golf bag support	7	Front wheel
4	Rear wheels	8	Axis frame



4 Assembly instruction

1. Unpack all items and check inventory.
2. Attach rear wheels to axis frame by pushing the wheel locking buttons on the wheel and inserting the axle extension into the wheel (see fig. A).
3. Make sure to keep the spring clip on the wheel pressed down during this process, in order to enable the wheel to be inserted fully onto the axle sprocket. If you have inserted the wheel correctly onto the wheel, when you release the spring clip it will lock onto a groove on the end of the axle. Test the lock by trying to pull the wheel out.



Fig. A



Fig. B

WHEELS LOCKING



- The wheel with the toothed hub must be mounted on the parking brake side.
- Do not leave the caddy on sloping ground before applying the brake.
- Do not force the wheels onto the axle without pushing the wheels locking buttons. this operation could irreparably damage the wheel.



4. Install the front frame of the caddy on the axis frame. a click identifies the correct assembly of the frame.
5. Install the rudder frame of the caddy on the axis frame. a click identifies the correct assembly of the frame.
6. Adjust the height of the drawbar and the positioning of the golf bag holder. Once the desired position has been reached, lock the rudder by turning the fixing knob clockwise, as shown in **Fig. C**.




Fig. C

7. Place your golf bag on the trolley, securing it with the dedicated fastening elastic bands, as shown in **Fig. D**



Fig. D



4.1 Braking system

The caddy is equipped with a lever train located in conjunction with the right rear wheel. to activate the brake, press the lever downwards using your foot (**Fig. E**), making sure that the brake pin fits into one of the grooves in the wheel hub.

To release the brake, lift the lever upwards (**Fig. F**).



Fig. E



Fig. F

4.2 Accessories

The caddy can be equipped with the following accessories:

- Score card holder.
- Cup holder.
- GPS/Smartphone holder.
- Umbrella holder.
- Rain cover
- Transport trolley



¹ The caddy TERRA MANUAL FULL is already equipped with all the accessories mentioned.



5 Maintenance

All these recommendations, together with common sense, will help keep your caddy in top condition and ensure its reliability over time.

To keep your caddy looking its best, wipe any mud or grass off the frame and wheels after each use, using a damp cloth or paper towel.

Never use water jets or pressure washers to clean the Caddy to prevent moisture from entering the electronic systems motors, or gearboxes.

Dry your caddy properly after each use,

Weekly, remove the rear wheels from the axle and carefully clean the tires from any debris that could cause the wheels to drag.

You can apply silicone-based lubricant to keep moving parts smooth and corrosion-free.

Inspect your trolley carefully at least once a year and, if you notice any signs of wear or malfunction, contact GEEN EAGLE GOLF assistance to have them suggest the recommended intervention to guarantee a long life to your caddy.

5.1 Troubleshooting guide

Trouble	Possible solution
Problems attaching wheels	• Make sure you are holding the spring clip down. • Sand and smooth axle with emery cloth to remove excess paint or burrs.
Brake doesn't work	• Make sure you have installed the wheel with the splined hub on the brake lever side.



6 Technical data

- Weight: 12,5 lbs
- Material: Stainless Steel
- Max Load Capacity: 85 lbs
- Size Folded: 33x27x13 in
- Size Unfolded: 43x24x36 in (adjustable)
- Shipping Box Weight: 16 lbs
- Shipping Box Dimensions: 31.5×13.7×11.4 Inch.
- Wheels Specs: Front wheel diameter: 6 Inch, Rear wheel diameter: 12 Inch, Non-swivelling front wheel.



7 Customer service - technical assistance

In case of need to communicate malfunctions of your caddy or order spare parts not present on our e-commerce, contact GREEN EAGLE GOLF assistance at the following contact details.



Website: www.greeneaglegolf.com

E-mail: support@greeneaglegolf.com

Telephone: (786) 912-2571



[greeneagle_golf](https://www.instagram.com/greeneagle_golf)



[Green Eagle Golf](https://www.facebook.com/GreenEagleGolf)

This document and its contents are the property of Green Eagle Golf all rights are reserved and the contents cannot be reproduced, even partially, without written authorization from the manufacturer.