




DESCRIPTION	DIAGRAM #	RHYTHM ITEM #
Pre-Filter Cover	1	P2E7PFCR
Nozzle	2	P2NZL-2
Sealing Ring	3	P2SLR-2
Main Case	4	P2MNC-2
st2.2*5 304 Stainless Steel	5	P2SC225-2
Cable Cover on Main Case	6	P2CCMC-2
Display Panel (Keyboard)	7	P2E7-3
Post Filter Assembly	8	P2E7-10
Air Outlet Seat	9	P2AOS-2
Leather Cup	10	P2LRC-2
Main PCB w/Screen	11	P2E7-6
PU Tube	12	P2PUTB425-2
Compressor	13	P2E7-2
st2.9*6 304 Stainless Steel	14	P2SC296-2

DESCRIPTION	DIAGRAM #	RHYTHM ITEM #
Heat Shrinkable Tube	15	P2HSTB945-2
Structural Plate	16	P2E7-9
Sieve Bed	17	P2E7-7
Front Solenoid Valve Control Line with Locking Connectors	18	P2E6FSV
Battery	19	P2BY001-2
Sieve Bed Compartment Cover	20	P2E7-8
st2.9*8 304 Stainless Steel*	21	P2SC298-2
st2.9*12 304 Stainless Steel**	22	P2SC2912-2
Bottom Base	23	P2E7-15
Anti Slip Mat	24	P2ASM-1
Pack for Cooler and Fixed Mount Accessories	25	P2E7-4

* 4 for Pack for Cooler and Fixed Mount Accessories, 2 for Structural Plate, 1 for Sieve Bed(right).

** 4 for Main Case, 4 for Compressor, 2 for Sieve Bed Compartment Cover, 1 for Sieve Bed(left).