


DESCRIPTION	DIAGRAM #	RHYTHM ITEM #
Flow Meter	1	LM10A-1
Front Panel Sticker	2	LM10A-2
Bacterial filter	3	LM10A-BF
LCD Monitor	4	LM10A-4
Front Cover Bracket	5	LM10A-5
Oxygen Outlet Connector	6	LM10A-6
Fence board	7	LM10A-7
Overload Protector	8	LM10A-8
Velcro	9	LM10A-9
Switch	10	LM10A-10
Inlet filter	11	LM10A-ILF
Pressure Regulation Valve	12	LM10A-12
Oxygen Sensor	13	LM10A-13
Gas Cylinder Cover	14	LM10A-14
Oxygen storage tank	15	LM10A-15
Fan	16	LM10A-16
Intake Muffler	17	LM10A-17
Inlet Filter Socket	18	LM10A-18
Filter Bracket	19	LM10A-19
Retaining Ring	20	LM10A-20
Molecular Sieve Cover	21	LM10A-21
Molecular sieve plate	22	LM10A-22
Pressure equalizing valve	23	LM10A-23
Molecular sieve cylinder	24	LM10A-24
Filter Door	25	LM10A-25
Back Cover	26	LM10A-26
Capacitance	27	LM10A-27
Solenoid valve	28	LM10A-28
Capacitor clamp	29	LM10A-29
Caster wheels	30	LM10A-30
Control PCB	31	LM10A-31
Base Panel Assembly	32	LM10A-32



DESCRIPTION	DIAGRAM #	RHYTHM ITEM #
Compressor Foot Pad	33	LM10A-33
Nitrogen Exhaust Muffler	34	LM10A-34
PCB board bracket	35	LM10A-35
Cooling Tube	36	LM10A-36
Partition	37	LM10A-37
Upper partition	38	LM10A-38
Compressor	39	LM10A-39
Front Cover	40	LM10A-40
10L Tubing, 0.5m	41	LM10A-41
Small Mesh Screen	42	LM10A-42
Air Filter End Cap	43	LM10A-43